


## Asset Failures (ICMS)



Loco failures navigation menu

- Click on "Loco Failures side menu and select "Loco Asset failures" navigation menu.
- Application allows the user to view the Asset failures by entering the Loco number and other relevant details in the "Managing Asset failures page.
- On clicking  button, the details are displayed in a tabular format.

View Asset Failure(ICMS)

Loco  From  To

Showing 20 Record(s) Out of 93

S.No	Loco	ICMS Sub Code	Date of Occurrence	Failure Code	Failure Responsibility	ICMS Remarks	Section Of Occurrence	Attention	Detention	Sch	Inward On	Online Att Loc
1	<a href="#">41078</a>	ECRW	28/09/2022 12:45 PM			BCN/MDTI LOCO 41078 DETN AT G/CAB FROM 12.45-13.35 HRS DUE TO DRIVER LATE ARRL AT 13.35 HRS. LP- SRI AMRESH KUMAR/DGG T.O.-12.45 HRS. (TLC REMARK:-)	GCAB	--	--		--	<a href="#">Update</a>
2	<a href="#">37085</a>	ELFG	26/09/2022 02:40 PM			TRAIN no 12149 11 loco loss between DOE to BQF engine no 37085(P-7) LGD load 23=46	JBP-STA	--	--		--	<a href="#">Update</a>
3	<a href="#">31131</a>	EPS	26/09/2022 12:30 PM			Goods fato:- LE/LONI 31131 (WAG-9,LGD)ord.for CONCOR but LP reported sanders trouble,same attended by Mechanic & given rdy at 14.45 hrs. Rep:- LE detain in GIT yard for 02 hrs.	PUNE-DD	--	--		--	<a href="#">Update</a>

Managing asset failures

### c. Update Asset failures:

- User updates the required information by clicking on "[Update](#)" link in "Managing Asset failures page".
- "Update Asset failures" page is shown.
- Click on  button after updating the necessary details.
- User receives successful message; the given information is updated accordingly.

### Update Line Failure

**Defect Type**  **Occurrence On**  **Loco Unit**  Single  Multi **Last Visit:** IT- 18/07/2021 - ELS/LGD

Loco	Type	Service	Base Shed	Major Sch.	Sch.Done On	Sch.Done At	Minor Sch.	Sch.Done On	Sch.Done At	TI Done on	TI Done At
41078	WAG	<input type="text" value="Selec"/>	LGD	<input type="text" value="Selec"/>	--	<input type="text" value="--Select--"/>	<input type="text" value="Selec"/>	--	<input type="text" value="--Select--"/>	--	<input type="text" value="--Select--"/>

Section/Station Of Occurrence	<input type="text" value="GCAB"/>	Zone	<input type="text" value="SECR"/>	Division	<input type="text" value="R"/>
Train No	<input type="text"/>	Station (After)	<input type="text" value="--Select--"/>	Station (Before)	<input type="text" value="--Select--"/>
Direction	<input type="text" value="--Select--"/>	Gradient	<input type="text" value="Select"/>	Load	<input type="text"/> (Tons)
Detention	<input type="text" value="--Select--"/>	Repurcussion	<input type="text" value="--Select--"/>	Punct.Loss	<input type="text" value="--Select--"/>
Wagons / Coaches	<input type="text"/> (No)	No.of Units	<input type="text"/> (No)		
Service Withdrawal	<input type="text" value="--Select--"/>	Withdrawal Place	<input type="text"/>	Withdrawal On	<input type="text"/>
Section KM/Pole No	<input type="text"/>	Reported	<input type="checkbox"/> Division <input type="checkbox"/> HQ <input type="checkbox"/> RB <input type="checkbox"/> E&R		

**ICMS Remarks**

*Update asset failures*