

Amrit Bharat Loco

Commissioning and conversion of Amrit Bharat Locos for WAP5 and WAP7 have been covered in SLAM. Concerned Sheds can change loco type WAP5 and WAP7 to WAP5AB and WAP7AB respectively.

- i. Login through Admin
- ii. Go to Correction ---> Loco master ----> Click on loco no.
- iii. Concerned Sheds can change loco type by clicking on check box as shown below.

The screenshot displays the 'Update Loco Master' form in the SLAM system. The 'Loco Type' is currently set to 'WAP5'. A red box highlights the 'Amrit Bharat' checkbox, which is unchecked. A dropdown menu is open over the 'Corrections' menu item, with 'Loco Master' highlighted in blue. The form includes fields for Loco Number (30045), Make (CLW), Loco Control (GTO), Nomination Types (Mail Express), Crew Friendly Modification (No), Cab 1 AC (Yes), Cab 2 AC (Yes), HLC (Yes), and RTIS (Yes).