

## MTR Locos

User shall have provision to add/view/update details during the time of MTR locos.

### a. New MTR locos:

Here user can view details like Purpose of Last Visit, Inward time, Outward time and can assign Date taken, Work Shop, Remarks.

### Add MTR Loco

Loco	30347
Previous Visit	Purpose: IC Inward On: 05/05/2022 00:00 Outward On: 06/07/2022 00:00
Date Taken	08/08/2022
Workshop	PER
Remarks	-

### b. Update MTR loco:

This screen allows to update/track MTR Loco information based on filter option.

Managing MTR Loco View

[Add MTR Loco](#)

Loco      Status      From      To

--All--    Not Completed        08/08/2022    Go

S.No	Loco	Started On	Completed On	Workshop	Remarks	Change Equipment
1	<a href="#">30347</a>	08/08/2022	--	PER	--	

**Update MTR Details** X

Date:

Details: 

MTR loco updated

Sch. Completed

**c. View MTR loco:**

This gives the provision to view MTR Loco information such as Loco, Started On, Completed date, Work shop and Remarks also.

Managing MTR Loco View

[Add MTR Loco](#)

Loco      Status      From      To

--All--    Not Completed        08/08/2022    Go

Showing 1 Records Out of 1

S.No	Loco	Started On	Completed On	Workshop	Remarks	Change Equipmen
1	<a href="#">30347</a>	08/08/2022	--	PER	--	