


Shed Outage

Application allows the user to calculate the performance outage targets received from HQ (Headquarters)/Concerned Officers.



Planning navigation menu -

a. View shed outage:

➤ Shed Outage details are shown in "View Shed Outage" Click on button to view the details either in Tabular format.

View Shed Outage

Date

S.No	Service Type	Kind	LocoType	NetHolding	Ineffective	Target	Shed Outage	Difference
1	Goods	3 Phase	WAG9/WAG9H	147	74	133.0000	73	-60.0000
2	Passenger	3 Phase	WAP7	121	51	115.0000	70	-45.0000