

Add Cracks

Given provision for PPIO to update or correct the key parameters of the loco under 'corrections' main menu.

- User shall select the 'Crack Register option from 'Shop Floor' side menu.
- Managing Cracks Register' screen shall be displayed with 'Add Cracks' link.
- User shall click on 'Add Cracks' link to add the details.
- In this Technical section supervisor shall have provision to select the Type, Loco No., Eq. number, etc...
- In this Screen Technical section supervisor shall have provision to add the Crack details like..
 - Loco No.
 - Crack In
 - Date
 - Attended by
 - Eq. Number
 - Eq. Position
 - Total point
 - Zone
 - Electrode Type
 - Crack Length
 - Lifting
 - No. of wall
 - Crack(old/new)
 - Electrode Classification
 - Brand name
 - Place
 - Repair Done

Add Cracks Register

Loco: 27107 | Crack In: Bogie | Add

Date: | Attended By: --Select--

Select	S.No	Eq.Number	Eq.Position	Total Point	Zone	Electrode Type	Electrode Make	Crack Length(cm)	Lifting	No.Of Wall	Crack (Old/New)
<input type="checkbox"/>	1	342-B	1	0	--Select--	--Select--	--Select--		--Select--	--Select--	--Select--
<input type="checkbox"/>	2	344-A	2	0	--Select--	--Select--	--Select--		--Select--	--Select--	--Select--

Save

b. Crack Rehabilitation:

- User shall select the 'Crack Register' option from 'Shop Floor' side menu.
- Managing Cracks Register' screen shall be displayed with 'Crack Rehabilitation' link.
- User shall click on 'Crack Rehabilitation' link to View the details.
- In this Technical section supervisor shall have provision to select the Type, Loco No., Eq. number, etc...
- In this Screen Technical section supervisor shall have provision to View the Crack Rehabilitation details like...
 - Type
 - Eq.Name
 - Eq. Number
 - Electrode Make
 - Eq. Position
 - Zone
 - Loco No.
 - Criticality Factor
 - Total point
 - Rehabilitation
 - Date
 - Last Modified on
 - Attended by
 - Supplier

Cracks Rehabilitation														
Type	Loco	Eq. Number												
--All--				oo										
S.No	Type	Eq.Name	Eq.Number	Electrode Make	Eq.Position	Zone	Loco	Criticality Factor	Total Point(cm)	Rehabilitation	Date	Last Modified On	Attended By	Supplier
1	Bogie	BGF-G7	382-A	CLW	2	C30	27710	0.05	10	1	--	--	Anil Sharma	
2	Bogie	BGF-G7	641-B	CLW	1	C30	27709	0.05	20	2	--	--	Anil Sharma	
3	Bogie	BGF-G7	703-A	CLW	2	C30	27707	0.05	10	1	--	--	Anil Sharma	
4	Bogie	BGF-G7	705-B	CLW	1	MISC	27464	0.06	20	2	--	--	Anil Sharma	
5	Bogie	BGF-G7	268/A	CLW	1	MISC	27456	0.06	10	1	--	--	Anil Sharma	
6	Bogie	BGF-G7	223/B	CLW	2	MISC	27454	0.06	20	2	--	--	Anil Sharma	
7	Bogie	BGF-G7	3130	CLW	1	MISC	27454	0.06	20	2	--	--	Anil Sharma	
8	Bogie	BGF-G7	5-31	CLW	1	MISC	27453	0.06	10	1	--	--	Anil Sharma	
9	Bogie	BGF-G7	125/A	CLW	2	MISC	27355	0.06	10	1	--	--	Anil Sharma	
10	Bogie	BGF-G7	315/B	CLW	2	MISC	27351	0.06	10	1	--	--	Anil Sharma	
11	Bogie	BGF-G7	411-B	CLW	1	MISC	27351	0.06	20	2	--	--	Anil Sharma	
12	Bogie	BGF-G7	644-A	CLW	2	MISC	27327	0.06	20	2	--	--	Anil Sharma	
13	Bogie	BGF-G7	486-A	CLW	2	MISC	27313	0.06	20	2	--	--	Anil Sharma	